










RM 8

Core and accessories

	Individual parts	Part no.
	Adjusting screw	B65812
	Core	B65811
 	Clamps	B65812
	Insulating washer 1	B65812
	Coil former	B65812
	Core	B65811
	Threaded sleeve (glued-in)	
	Insulating washer 2	B65812

FRM0051-5

Example of an assembly set

Also available:

Coil former for SMPS transformers	B65812
Coil former for power applications	B65812
<u>RM 8 low-profile:</u>	
Core	B65811P
Clamp	B65812
Insulating washers 1 + 2	B65812